

# Three-dimensional **Morphological Reconstruction** of Millimeter-Scale Soft Continuum Robots based on **Dual-Stereo-Vision**

Tian-Ao Ren<sup>1,2,3</sup>, Wenyan Liu<sup>1</sup>, **Tao Zhang (Presenting)**<sup>1</sup>, Lei Zhao<sup>3,4</sup>


Hongliang Ren<sup>1,3</sup>, Jiewen Lai<sup>1,3</sup>

<sup>1</sup>EE, CUHK

<sup>2</sup>ME, Stanford University

<sup>3</sup>CUHK Shenzhen Research Institute

<sup>4</sup>CSE, Hunan University




# Background – Morphological Reconstruction for Robot's Self Modeling

## Why

- **Self Modeling:** The ability for a robot to **simulate its physical self**
- Essential for **robot motion planning and control** – when the robot has **complex morphology (outlook)**

## Current

- **General setup:** A **multi-depth-camera system** for morph data collection
- Only for **well-structured large rigid robots** (meter-scale)



Chen et al., **Sci. Robot.** (2022)

# Target – Notched Tubular Continuum Robots (NTCR)


## Problems

- Notch's geometric parameters significantly affect the deformation

→ Benefit from self-modeling


- Challenging to reconstruct small body & notches (length < 1 mm)

→ Need either better camera (hardware) or improved algorithm (software)




How to reconstruct the soft robot on a millimeter scale?

# Existing Solutions



Rong & Gu, **IEEE RA-L** (2024)

- Tri-RGB-D camera system
- Large diameter: 18 mm for a single soft robot
- Simplified to parameterized B-spines
- CNN for training (Images)




Zheng et al., **Adv Intell Syst** (2024)

- Dual-RGB camera system
- Large diameter: 40 mm for a single soft robot
- Simplified to parameterized Key Points
- CNN for training (Key points)

**Shape Reconstruction** for large soft robots with simple geometry  
(cylindrical shape)

# Ours



T.-A. Ren et al, **ROBIO** (2024)



## What's new

- Dual stereo vision-based **3D morphological reconstruction** method for **millimeter-scale** soft continuum robots
- KD-tree-based point cloud optimization for improved morphological reconstruction

## Performance

Reconstruct the notched robot's shape with clear details, **identifying 1.5 mm-width notches**


# Setup



- **Point cloud acquisition platform:** Dual stereo cameras in the opposite direction
- **Camera-Object distance:** 90 mm
- **Target Robot:** 3.5 mm diameter, 50 mm length

**Comparison:** 3D Point Clouds captured by Intel RealSense (a) D405 and (b) D435i.

# Preliminary 3D Reconstruction



**Statistical Outlier Removal (SOR)** is used to identify and exclude points that significantly deviate from their neighbors

$$\delta_{Threshold} = \mu + \alpha\sigma$$


$\mu$ : the mean distance (easily tuned within the setup)

$\sigma$ : the standard deviation of distances

- Showing the robot in detail, including its curvature and notches
- Fail to represent the **cylindrical appearance** of the tiny robot

**Needs further optimization**

# Optimization with K-Dimensional Tree



## Optimization workflow

1. For raw 3D point cloud (PC):
  1. Extract geometric backbone
  2. Generate a corresponding cylinder with a pre-defined diameter
2. Align the PC to the cylinder surface with the **KD tree** and **iterative closest point (ICP)** algorithms



# Optimization with KD-Tree

## Point Cloud Alignment with ideal cylinder


Iterative closest point (**ICP**) :

- Align the target point cloud to the reference point cloud
- It iteratively solves for the transformation matrix  $T$  as

$$T = \arg \min_T \sum_i \|p_i - (Rq_i + t)\|^2$$

$p_i$  : Points in the target point cloud

$q_i$  : Corresponding points in the reference point cloud



**Iterative Refinement Results**

# Results


**Metrics: Point Density Consistency (PDC):**

$$\lambda_{PDC} = \frac{\sigma_{PDC}}{\mu_{PDC}}$$

$\sigma_{PDC}$ : standard deviation of point counts per voxel


$\mu_{PDC}$ : mean of point counts per voxel

## PDC heatmap



**With optimization**  
(Gen-backbone + KD-tree + ICP )

**Without optimization**  
Sparse Point Cloud



## Measurement results on the visible notches' width

Successfully reconstructed mm-scale continuum robot morphology with clear details:

- **14 out of 16** notches
- Notches with a width of **1.5 mm**
- Point Density Consistency Analysis:

Point Clouds	$\mu_{PDC}$	$\sigma_{PDC}$	$\lambda_{PDC}$
Point Clouds 1 (Optimized)	1.5489	3.9636	2.5590
Point Clouds 2 (Non-optimized)	0.9582	2.2759	2.3752

# Conclusion

- Proposed a **dual stereo vision** method for 3D reconstruction of millimeter-scale **NTCRs**.
- Achieved **high-resolution, cost-effective,** and **precise** results.

## Future work

- **Real-time reconstruction** for dynamic soft robot
- **Self-modeling** for soft robots

